

# TRIMLESS

■ astro

## 5623 / 5624

**GB**

Please read the instructions carefully before commencing assembly

Live : Normally Brown / Red  
Neutral : Normally Blue / Black

**F**

Lire attentivement les instructions avant de commencer le montage

Phase : Normalement Brun / Rouge  
Neutre : Normalement Bleu / Noir

**E**

Leer atentamente las instrucciones antes de comenzar el montaje

Fase : Normalmente Marro / Rojo  
Neutro : Normalmente Azul / Negro

**D**

Lesen Sie bitte die Anweisungen sorgfältig durch, bevor Sie mit dem Zusammenbauen beginnen

Phase : Normalerweise Braun / Rot  
Nulleiter : Normalerweise Blau /Schwarz


For ceiling use only.  
Seulement pour montage au plafond.  
Nur für den Deckengebrauch.  
Para utilizar sólo en techos.








Not suitable for mounting **in** flammable materials, e.g. wood.  
Nicht für das Anbringen **in** flammbaren Material geeignet.  
Ne convient pas pour montage **dans** des matériaux inflammables.  
No apto para el montaje **dentro** de materiales inflamables.




Not suitable for covering with thermal insulation.  
Nicht für die Abdeckung mit Wärmedämmung geeignet.  
Ne peut être recouvert de matériaux d'isolation.  
No apto para cubiertas con aislamiento térmico.







5




6




**7** 5623 (12v)



5624 (230v)



**8**



**9**

