



Instructions

Type nr: 20241-22

Contents

- A. Cordset
- B. Base
- C. Shade in glass

Not included with purchase

Light source E14 bulb, max 40W or 6W LED.

Remember to use a LED bulb. Led bulbs use up to

Cleaning instructions

Product may be cleaned only after it has been switched off and cooled down.

Prevent moisture from getting to the lamp connections or power supplying elements.

Wipe the surface with a soft, damp sponge or cloth and wipe immediately with a dry cloth.

We do not recommend cleaning agents as they can cause staining.

After cleaning, the lamp should be left off until it dries completely.

