

# INSTALLATION MANUAL

38118LA, 38136LA, 38145LA

**ecolight**




80  
CRI




100-240V | SMD 2835 | 18W / 36W / 45W | 50/60Hz | IP65 | PC

Complete with driver





**one**  
LIGHT

A



B



## Warnings:

1. Make sure that the product is installed properly before connecting to electricity.
2. Do not cover the fitting.
3. Maintenance and installation should only be carried out by a professional electrician.