


INSTALLATION MANUAL

38136R

ecolight





100-240V | 50/60Hz | 22W | IP20 | 30000 Hrs


Complete with driver.



one
LIGHT



SCREWS 4x20mm
0.6N/m



Warnings:

1. Make sure that the product is installed properly before connecting to electricity.
2. Do not cover the fitting.
3. Maintenance and installation should only be carried out by a professional electrician.