

# INSTALLATION MANUAL

## 61080


**ecolight**


ADJUSTABLE







3W LED + 40W E27 | 230V | IP20 | Metal + white fabric shade | Adjustable | USB

Complete with driver.


**one**  
LIGHT

- Mark on the wall the selected location for the wall-mounting bracket, drill holes for wall plugs and insert them into the wall.
- Attach the mounting bracket to the wall and secure with screws.
- Connect the electrical wires as shown in the diagram.
- Place the fixture to the wall and align back plate to the mounting bracket. Secure with screws.
- Place the lampshade onto the lampholder.
- Use the ring to secure the lampshade on the lampholder.
- Install lamp (Do not exceed the maximum wattage rating).


**G**

**F**

**E**

**C**

**A**
**B**
**D**

### Warnings:

- Make sure that the product is installed properly before connecting to electricity.
- Do not cover the fitting.
- Maintenance and installation should only be carried out by a professional electrician.