


# INSTALLATION MANUAL

61130

**ecolight**


230V | 5W | IP20 | ABS + aluminium | Dimmable | Adjustable

 4 steps CCT  
 USB output  
 USB charging socket  
 Wireless charger


<p><b>A</b></p>	<p><b>B</b></p> <p><b>WIRELESS CHARGING APPLICABLE DEVICES:</b></p> <ol style="list-style-type: none"> <li>1. Devices with built-in wireless charging receiver.</li> <li>2. Devices with reserved wireless charging interface beside its battery.</li> <li>3. Devices with wireless charging receiver in its protection case.</li> </ol>
<p><b>C</b></p> <p>When using the wireless charging function, place phones with Qi receiver onto the wireless charging area. At this time, the wireless charging indicator turns on and flicker to indicate that wireless charging works properly. The indicator turns off after the phone is removed.</p>	<p><b>D</b></p> <p>To charge a digital device, use a piece of charging cable to connect the USB output port of desk lamp with the charging port of the device.</p>

## Warnings:

1. Make sure that the product is installed properly before connecting to electricity.
2. Do not cover the fitting.
3. Maintenance and installation should only be carried out by a professional electrician.